

GAME CONTROLLER RUNNING TIME / ACTUAL TIME

TO ADJUST CLOCK TO RUNNING/ACTUAL TIME:

- 1 Power on/off (Button left side)
Set time using + min or - min button to your game time
2. Press the red '**FUNC'N ENTER**' button in the bottom right corner of the game controller (a small 'f' should appear on the game controller screen)
3. Press the blue '**START STOP**' button directly to the left of the function button
4. The controller screen will show 'Shot Clock Reset Seconds?-> 28', click the red '**FUNC'N ENTER**' button to continue
5. The controller screen will show 'STOP GAME TIMER WHEN SC = 00 Y/N', press the '**-MIN/NO**' button to continue
6. The controller screen will show 'STOP ALL CLOCKS ON SCORE' Y/N'
 - For **RUNNING TIME** press **NO** (the '**-MIN/NO**' button)
 - For **ACTUAL TIME** press **YES** (the '**+MIN/YES**' button)
7. The controller screen will show 'STOP/START GT with SC Y/N'
 - For **RUNNING TIME** press **NO** (the '**-MIN/NO**' button)
 - For **ACTUAL TIME** press **YES** (the '**+MIN/YES**' button)
8. The controller screen will show 'EXCLUSION TIME SECONDS?-> 18', click the '**+MIN/YES**' button Then press '**FUNC'N ENTER**'
10. Auto SC Reset on score Y/N? Press YES (the '**+MIN/YES**' button)
11. The controller screen will show 'ENABLE ALT SHOT TIMER Y/N', click the '**+MIN/YES**' button
12. The controller screen will show Alt shot clock seconds? - '18' click red '**FUNC'N ENTER**'

You are ready to start

PROG'M
FUNC'N
ENTER
Next →

TIME OUTS
**START
STOP**

PROG'M
FUNC'N
ENTER
Next →

**+ MIN
- SEC**
No

ADJUST
**+ MIN
- SEC** Yes
**+ MIN
- SEC** No

**+ MIN
- SEC**
Yes

**+ MIN
- SEC**
↑ Yes
A

PROG'M
FUNC'N
ENTER
Next →



Water Polo
WESTERN AUSTRALIA