



**These systems have now been set up to run only 5-minute actual time games and cannot be adjusted in accordance with the Competition Rules.**


- 1) Press Power On/Off button (top left corner). The system will load all preset conditions, and you will see the setup screen.



- 2) Press the shot clock reset button.



- 3) Play the game 😊 See attached pages for controls during the game
- 4) At the completion of the game, press the “New Game/ESC” button on the right-hand side. This will reset the whole system for the next game.





# Water Polo

WESTERN AUSTRALIA

## GAME CONTROLS

Electronic Scoreboards Australia CC-12 WP

SCORES Exclusion Player 2 Exclusion Player 1 TIME MIN SEC

0 0 0 b 5:00  
0 0 0 1 28

A Light  
B Dark

POWER on/off

SCORE A 6 +1 PQR  
B 2 +1 DEF

DOUBLE Exclusion 8 +2 VWX  
SINGLE Exclusion 9 +1 YZ sp

ERROR -1 ← Prev  
+1 P X-TIME  
NEW GAME ESC

TIMER 0 RESET ABC  
ADJUST + MIN + SEC - MIN - SEC  
TIMER 1 START HOLD  
TIMEOUT START STOP  
PROG'M FUNC'N ENTER

↑ Yes ↓ No B

Next →

Exclusion White Team  
Goal White Team

Electronic Scoreboards Australia CC-12 WP

SCORES Exclusion Player 2 Exclusion Player 1 TIME MIN SEC

0 0 0 b 5:00  
0 0 0 1 28

A Light  
B Dark

POWER on/off

SCORE A 6 +1 PQR  
B 2 +1 DEF

DOUBLE Exclusion 8 +2 VWX  
SINGLE Exclusion 9 +1 YZ sp

ERROR -1 ← Prev  
+1 P X-TIME  
NEW GAME ESC

TIMER 0 RESET ABC  
ADJUST + MIN + SEC - MIN - SEC  
TIMER 1 START HOLD  
TIMEOUT START STOP  
PROG'M FUNC'N ENTER

↑ Yes ↓ No B

Next →


Exclusion Blue Team  
Goal Blue Team



# Water Polo

WESTERN AUSTRALIA


Start the game and shot clock - This button will start both in an actual time game



Stop the game and shot clock - This will stop both clocks in actual time game

Provide a second 18 second shot clock - When a team gets a corner, has a shot and recovers the ball from a rebound/deflected shot that stays in the field of play

28 second shot clock reset - When a team takes possession from the opposition or after a goal throw is awarded. THERE IS NO NEED TO PRESS THIS BUTTON AFTER A GOAL, WHEN YOU PRESS THE SCORE BUTTON THE SYSTEM AUTOMATICALLY RESETS.



If you make an error like entering the score against the wrong team press this button